



Connector A

1. Not connected (**purple**)
2. Car brake control (**brown**)
3. --
4. Memory +12V (**yellow**)
5. Remote +12V output (**blue**)
6. Access reversing (**green**)
7. +12V ignition (**red**)
8. Ground (**black**)

Connector B

1. Rear R Speaker (+)
2. Rear R Speaker (-)
3. Front R Speaker (+)
4. Front R Speaker (-)
5. Front L Speaker (+)
6. Front L Speaker (-)
7. Rear L Speaker (+)
8. Rear L Speaker (-)